

Product			Application		Required Maintenance Steps
	Required	Finish		Maintenance Cycle	Required Maintenance Steps
Designer Ipe	None, it comes dried and sanded ready for prefinishing	Messmers UV-Plus for Hardwoods Finish	1 coat on all sides and ends	1 to 3 years depending on traffic and exposure to the sun	Prior to refinishing, mix cleaning solution of 2 oz. TSP, 1 quart bleach, 3 quarts of water. Using a pump garden sprayer, spray solution on a wetted deck, let sit 15 minutes, and then power wash. Allow to dry 2 days, then apply one coat Messmers UV-Plus for Hardwoods Finish
Designer Ipe	None, it comes dried and sanded	With Designer Ipe you have the option to not apply a finish and allow it to weather to a soft silver gray	N/A	Annually	Mix cleaning solution of 2 oz. TSP, 1 quart bleach, 3 quarts of water. Using a pump garden sprayer, spray solution on a wetted deck, let sit 15 minutes, and then power wash.

www.kwaterskibros.com

Nation's Largest Selection of Creative Wood Products